

## RT97L Firmware Upgrade Guide

1. Prepare the following two files on your computer in advance:


- ① Upgrade tool (application program)
- ② Firmware upgrade file (with a .bin file extension)




2. Double-click the upgrade tool icon to launch the application.



3. Click “COM”, select the appropriate COM port, and then click “OK” .




4. Click “Open File”, select the firmware file with a .bin extension, and click “Open” .




5. Once the file is successfully loaded, click “Start” .

**Note: Click “Start” on the computer first, and then power on the RT97L.**



6. Connect the RT97L to the computer using the programming cable, and turn on the power. The upgrade process will start automatically. A progress bar will appear at the bottom of the screen.



7. Once the upgrade is complete, a message indicating success will be displayed.

