





# Shenzhen Retevis Technology Co., Ltd.

7/F, 13-C, Zhonghaixin Science&Technology Park, No.12 Ganli 6th Road, Jihua Street, Longgang District, Shenzhen, China

Web: www.retevis.com E-mail: kam@retevis.com

Facebook: facebook.com/retevis



Made In China





User's Manual



# TO CUSTOMERS

Thank you very much for using our two way radio. This radio of modern design is reasonable structure with stable functions. It is designed to meet different customers' need for high quality with easy operation and perfect capablity. We believe you are pleased with its nice shape and excellent performance.

This manual is suitable for using the model of RT21V.

# **Contents**

- 01 Using tips
- 02 Unpacking and checking equipments
- 03 Getting familiar
- 04 Battery
- 07 Antenna
- 08 Installing and uninstalling of supplied accessories
- 10 Basic operation
- 13 English/Chinese Voice Prompt
- 17 Walkie talkie write frequency operation process
- 20 More Optional Accessories of Retevis
- 21 Optional Accessories
- 22 Trouble shooting guide
- 23 Safety Guide
- 32 Specifications

Warranty card



# Using tips

Please read the following brief instructions, non-compliance with these rules may cause danger or violate the law.

- Obey the local government regulation before using this radio, improper use may violate the law and be punished.
- Turn off the radio before entering flammable or explosive areas.
- Do not charge or change the battery in flammable or explosive areas.
- Turn off the radio before getting close to the blasting zone or detonator areas.
- Do not use radio whose antenna is damaged, touching of damaged antenna will cause heat injury.
- Do not attempt to open the radio; the maintenance work should be done by technical expert only.
- To avoid troubles caused by electromagnetic interference or electromagnetic compatibility, please turn off the radio in places where have the banner "Do not use wireless equipment", such as hospital and other healthcare places.
- In the car with an airbag, do not put the radio within the scope of the airbag deployment.
- Do not store the radio under the direct sunshine or in hot areas.
- When you transmit with the radio, do keep away from its antenna for 5cm at least.
- If the radio appears smelly or smoke, please shut off its power immediately and contact with your local dealer.
- Do not transmit too long, for the radio may heat and hurt the user.

# RETG/1S


# Unpacking and checking equipment

Welcome to use two-way radio. Carefully unpack the radio. We recom mend you check the items listed in the following table before discar ding the package. If any item is missing, please contact local dealer immediately.

# Supplied accessories:



Note: The antenna frequency range please refers to the annular label at the bottom of antenna.



# RETG/15

# **Battery**

Please use **RETE/IS** designated battery; other batteries can cause explosion and hurt people.

**Notice:** 1. Please do not short-circuit the battery terminals or expose of in fire. Do not dissemble the battery by yourself.

- 2. Charge the battery between temperature 0  $^{\circ}$ C and 45  $^{\circ}$ C. The battery can not be fully charged beyond this temperature range.
- 3. Please turn off the power when you charge the radio with battery. Transmit with the radio in charge will affect its correct charge.
- 4. Do not unplug the power or battery when it is charged.
- 5. The operating time becomes short even the battery is fully charged, the battery is exhausted, please replace battery.
- 6. Please do not charge when the battery or the radio is wet. Please dry it with a cloth before charging to avoid any danger.

Warning: When the conductive metals such as jewelery, key or decorative chains touch the battery terminals, all the batteries are likely to cause damage to the items or personal injury. These conductive metals may form a short circuit and generates much heat.
Do deal with any battery carefully, especially when put it into pocket, wallet or other metallic containers.



## Charging operations:

Charge the battery as follows:

- 1) Power off
- 2) Insert the DC adaptor plug in the DC jack on the back of charger
- 3) Insert the AC adaptor plug in the AC power output socket
- 4) Insert the battery or radio with battery vertically in a charger, to check whether the battery and charger terminal is in normal contact.
- 5) Make sure the battery and charger terminal is in good contact, when the charging indicator light turns red, it starts charging.

Note: 1. Before inserting the battery, it is abnormal if the charging indicator blinks

- 2. To change the battery for charging, please wait until the indicator is stable.
- When the battery is well inserted, the indicator turns red and the charging is on the process, if the indicator blinks, then the battery is damaged or the temperature is too high or too low.

### Self-testing

When the charger powers up, if the orange indicator lights for one second and then goes out, entering the standby mode, the charger passes the self-testing and can charge the battery. If the orange indicator blinks constantly, the charger fails to pass the self-testing, and can not charge the battery.

Normal charging indicator

When charging the battery, if the indicator light turns red, the battery is on the normal charge; if the red indicator light blinks constantly, the battery capacity is too low, and is on the trickling charge, and after the battery capacity reaches a certain level, it will switch to the normal charge.

**Note:** Trickling charge does not exceed 30 minutes, if the red indicator light blinks after 30 minutes, it means the charger can not charge battery, please check whether the battery or the charger has been damaged.

## Charging precautions:

- 1) The battery is not fully charged in factory, please charge before using it.
- 2) Charge and discharge the battery for two or three times, the battery capacity will reach the best condition. When the battery capacity is low, please charge or change the battery.
- 3) The battery lasts shortly even if it is fully charged, the battery is exhausted, please contact your local dealer to buy a new authentic **RETEVIS** battery.



### Antenna


- Short thick antenna is suitable for short-distance communication, while long thin antenna will offer you a better communication effect. Wearing the radio in your waist will not make you feel uncomfortable.
- The communication range will be shortened in bad weather or among the trees, please prepare in advance to avoid any inconvenience of your communication and security.



# Installing and uninstalling of the accessories

# Installing/Removing the battery

- 1) Align the two grooves of battery and the guide rail on the back of aluminum shell, ensuring full contact and in parallel, then push the battery up to the radio base along the rail on the back of aluminum shell, until the battery latch locks up. (picture 1)
- 2) To remove the battery, please make sure the radio is closed, push the battery latch down, and make sure the radio and battery is on the releasing state, and then push the battery out from the radio. (picture 2)






### Installing external headset

Reveal (do not remove) the mic/speaker jack cover (picture 7), insert the headset into the mic/speaker jack (picture 8).

Note: Using the external headset will affect the water-tightness performance of radio.



# **Basic operation**


## 1. Scan Function

When the radio is allowed to be scanned, which can be set by the software, you can press the Monitor key to turn on or turn off the scan. When the scan begins, indicators lights green, the radio will can scan automatically from channel 1 to 15 which is defined as scan added. When there is signal in the scanning channel, it will stop in the channel for talk.

#### Note:

When there is signal in the scanning channel, it will stop in the channel for a talk and after several seconds.

Please note that scan is only available when there are two or more than two memory channels and two or more scan added channels.



### 2. Battery Save Function

This function can be set by the software.

Turn on this function can make the standby time more longer.

In the software:

"Edit" →"Function Setup" → "Battery Save"

Off: Battery save function is off.

ON: Battery save function is on.



#### 3. Scrambler

When the radio is allowed the scrambler function, and press the key, TX voice will be sent out with scrambler, other radio only received the signal when its scrambler also turns on.

# 4 .Busy Channel Lock

You can turn on/off this function via software.

A: if the current channel does not have CTCSS/DCS, When there is signal, TX prohibited when you press PTT.

B: If the current channel does not have CTCSS/DCS, when there is signal which does not have CTCSS/DCS, TX prohibited when you press PTT.

C: If the current channels does not have CTCSS/DCS, when there is signal which have CTCSS/DCS, the radio will transmit when you press PTT.

### 5. Wide/Narrow Bandwidth

The occupied bandwidth of emissions transmitted on the center frequencies 151.820 MHz, 151.880 MHz, and 151.940 MHz are 11.25KHz; The occupied bandwidth of 154.570 MHz and 154.600 MHz are 20KHz.

#### 6.VOX

Speak to the microphone in normal voice to transmit, no need to press PTT switch, turn VOX on//off though the software.

A: when VOX is on in your working channel.

Speak to the microphone directly, it will transmit automatically.

The radio stops transmitting when there is no voice, and waits for receiving.

B: when a headset with a microphone is used.

When VOX is on, you should VOX again for the radio to identify voice volume.

If the microphone is too sensitive, the noise around radio will start transmitting.

If the microphone is not sensitive, the radio can not collect your voice, Please Adjust VOX level well to guarantee smooth communications.

# **English/Chinese Voice Prompt**

## Voice prompt

The default setting is Chinese voice prompt, and you will know the working condition of the radio with voice prompt.

- 1) The voice prompt can be selected "Chinese/English/Tone/OFF" through the menu "Voice/Beep Tone" of the "Optional Features" in the software for. When choosing "OFF", voice prompt turns off.
- 2) **Channel annunciation:** You will get to know the working conditions of current channel which is being operated.
- 3) **Low battery alert:** The radio will alert you when the battery capacity reaches the minimum operating voltage.

### Low battery prompt

The default setting is Chinese voice prompt. When transmitting or standby, if the battery capacity reaches the pre-determined low level, the indicator light blinks red, and a low battery alert tone will be heard.

The indicating tone can be "Please change the battery". When the low battery alert occurs, it can not transmit, please change or charge the battery.

## Squelch function

The squelch level will determine the signal strength to open the speaker of the radio. If the squelch level is lower, the background noise of opening the radios speaker will be higher, and the corresponding communication range will be further, but the anti-interference



capacity will be weaker.

The default setting of squelch level is 5, you can adjust it through the menu "Squelch Level" of the "Optional Features" in the software for. Level 0 to 9 can be selected. 0 is the lowest level.

### Time out timer (TOT)

The purpose of TOT is to prevent any radio from talking in one channel for a long time, and to prevent the transceiver from being damaged because of continuous transmission. If the transmitting time exceeds the TOT pre-set time, the radio will sound "Du". Release

### CTCSS/DCS

CTCSS and DCS is the sub-audio signaling, to prevent the radio from receiving unwanted signal in the same channel.

When the CTCSS/DCS is set, then within the communication range, you can only receive signals from the same channel with the same CTCSS/DCS setting. When the CTCSS/DCS is not set, you will get all the signal from the same channel within the communication range. You can set the CTCSS/DCS through the menu "QT/DQT ENC" or "QT/DQT DEC" of the "Channel Setting" in the software.

### Power protection function

When the radio is in normal use or maintenance, the transmission will be prohibited if the working voltage is beyond the normal supplying voltage. Lower than 3V or higher than 5V, the transmission will be prohibition. The radio cannot power on when it is higher than 5V.



#### CTCSS

| 67.0  | 69.3  | 71.9  | 74.4  | 77.0  | 79.7  | 82.5  | 85.4  | 88.5  | 91.5  |
|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| 94.8  | 97.4  | 100.0 | 103.5 | 107.2 | 110.9 | 114.8 | 118.8 | 123.0 | 127.3 |
| 131.8 | 136.5 | 141.3 | 146.2 | 151.4 | 156.7 | 162.2 | 167.9 | 173.8 | 179.9 |
| 186.2 | 192.8 | 203.5 | 210.7 | 218.1 | 225.7 | 233.6 | 241.8 | 250.3 |       |

### DCS

| 000   |       |       |       |       |       |       |       |       |       |
|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| D023N | D025N | D026N | D031N | D032N | D043N | D047N | D051N | D054N | D065N |
| D071N | D072N | D073N | D074N | D114N | D115N | D116N | D125N | D131N | D132N |
| D134N | D143N | D152N | D155N | D156N | D162N | D165N | D172N | D174N | D205N |
| D223N | D226N | D243N | D244N | D245N | D251N | D261N | D263N | D265N | D271N |
| D306N | D311N | D315N | D331N | D343N | D346N | D351N | D364N | D365N | D371N |
| D411N | D412N | D413N | D423N | D431N | D432N | D445N | D464N | D465N | D466N |
| D503N | D506N | D516N | D532N | D546N | D565N | D606N | D612N | D624N | D627N |
| D631N | D632N | D654N | D662N | D664N | D703N | D712N | D723N | D731N | D732N |
| D734N | D743N | D754N |       |       |       |       |       |       |       |
|       |       |       |       |       |       |       |       |       |       |

# RETG/15

| D023I | D025I | D026I | D031I | D032I | D043I | D047I | D051I | D054I | D065I |
|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| D071I | D072I | D073I | D074I | D114I | D115I | D116I | D125I | D131I | D132I |
| D134I | D143I | D152I | D155I | D156I | D162I | D165I | D172I | D174I | D205I |
| D223I | D226I | D243I | D244I | D245I | D251I | D261I | D263I | D265I | D271I |
| D306I | D311I | D315I | D331I | D343I | D346I | D351I | D364I | D365I | D371I |
| D411I | D412I | D413I | D423I | D431I | D432I | D445I | D464I | D465I | D466I |
| D503I | D506I | D516I | D532I | D546I | D565I | D606I | D612I | D624I | D627I |
| D631I | D632I | D654I | D662I | D664I | D703I | D712I | D723I | D731I | D732I |
| D734I | D743I | D754I |       |       |       |       |       |       |       |



# Walkie talkie write frequency operation process

I.System Requirements

Operating System: Windows98, Windows Me, Windows XP, Windows Vista, Windows7,

Windows8

Hard Disk Space: At least 50MB of available.

The minimum memory: 64M

### II.Install the write frequency line driver

- 1. Find the write line drive which your system corresponded to
- 2.Click to install, successfully installation is ok
- 3. installed, and open the write frequency software programming interface

## III.Write frequency software installation

Programming cable readying

- USB Programming cable need to install the driver before they write frequency
- Serial port Programming cable does not need to install the driver'it can directly write

## Computer terminal preparations

- Open the computer, run the computer operating system.
- Install the write frequency software which has been downloaded well or Install it From the programming software CD

Walkie Talkie end preparations

- USB(or serial)Programming cable connect the computer end
- The USB Programming cable pin is connected with one end of the walkie talkie programming interface
- Ensure the walkie talkie under the condition of power, open it.

# IV. Write frequency software operating process

- Find the software settings, open communication port, to ensure the communication port
   Option and computer connection port consistent (inconsistent will not read frequency) to
   solve the related problem
- 2. In the menu to find reading frequency and click in the window that appears can reading frequency
- This process needs waitting for a while, after the completion of reading the progress bar shows the walkie talkie channels and frequencies that have been read into the current software
- 4. Modify the walkie talkie channel and frequency data, and other functional parameter data
- 5. Find the write frequency in the menu ,click the appeared window to confirm , complete the progress bare
- 6. if multiple walkie talkie needs the same frequency, frequency steps can be repeated to write

# V:Related problem solving

When reading or writing frequency of walkie talkie long time no response or a communica-



#### tion error?

- check the write frequency line to find if it is damaged
- check wether the write frequency line with computer serial port or walkie talkie interface is bad or loose
- Check to find whether the walkie talkie battery is low or out of power, if this ,please replace the battery or charging the battery
- Check whether the programming software is match with the current model
- Please check whether the write frequency software port settings are assigned to the computer USB port
- Please check whether the power is switched on the walkie talkie
- Whether to choose the corresponding drive system and the correct installation

When writing the frequency is completed, found two walkie talkie cannot normal call or receive

- Make sure whether the two walkie-talkie are in the same channel
- Determine the same channel at the receiving end CTCSS, CDS and the transmitter is not the same
- 3. make sure whether the two walkie talkie' volume is too low, if it is too low ,Turn on the volume
- 4. Please check whether the two walkie-talkies are open, or at low/no power status
- 5. Check wether The walkie-talkie installed antenna
- 6. check and confirm wether the communication distance is too far

# More Optional Accessories of Retevis







Speaker microphone

6 in 1 programming cable kit

Acoustic Tube headset







Antenna

Throat mic


Programming cable

For more information, please visit our webiste: www.retevis.com

# Optional Accessories









RETG/15

Vehicle Charger

Speaker Antenna Adapter

Earphone



Clone Cable









Program Cable

Elliminator

Software CD

### RETE/IS

# Trouble shooting guide

| Troubles  | Solution   |  |  |  |
|---|--|--|--|--|
| No Electrical Source  | <ul> <li>The battery has been exhausted.</li> <li>Replace or recharge the battery.</li> <li>The battery is installed incorrectly.</li> <li>Remove it and install again.</li> </ul> |  |  |  |
| The operating time becomes short, even the battery is fully charged.            | Replace the battery.   |  |  |  |
| Not able to communicate with the transceivers of the same group.                | <ul><li>Confirm the QT/DQT is the same.</li><li>The distance is outside of range.</li></ul>  |  |  |  |
| The voice of another group can be heard.  | Change all QT/DQT of the group.  |  |  |  |
| Other radios can not receive the TX signals or receive signals in a low volume. | <ul> <li>Switch the volume knob to the highest level</li> <li>The microphone may be damaged, send it to the local dealer for check.</li> </ul>                                     |  |  |  |
| Noise is always heard.  | The distance is outside of range.  Turn on the radio in nearer range and try again.  |  |  |  |



# Rf Energy Exposure And Product Safety Guide For Portable Two-way Radios



Before using this radio, read this guide which contains important operating instructions for safe usage and RF energy awareness and control for compliance with applicable standards and regulations.

This two-way radio uses electromagnetic energy in the radio frequency (RF) spectrum to provide communications between two or more users over a distance. It uses radio frequency (RF) energy or radio waves to send and receive calls. RF energy is one form of electromagnetic energy. Other forms include, but are not limited to, sunlight and x-rays. RF energy, however, should not be confused with these other forms of electromagnetic energy, which when used improperly, can cause biological damage. Very high levels of x-rays, for example, can damage tissues and genetic material.

Experts in science, engineering, medicine, health, and industry work with organizations to develop standards for safe exposure to RF energy. These standards provide recommended levels of RF exposure for both workers and the general public. These recommended RF exposure levels include substantial margins of protection.

All Retevis two-way radios are designed, manufactured, and tested to ensure they meet government-established RF exposure levels. In addition, manufacturers also recommend specific operating instructions to users of two-way radios. These instructions are important because they inform users about RF energy exposure and provide simple procedures on how to control it.

Please refer to the following websites for more information on what RF energy exposure is and how to control your exposure to assure compliance with established RF exposure limits: http://www.who.int/en/

# RETG/15

## **Local Government Regulations**

When two-way radios are used as a consequence of employment, the Local Government Regulations requires users to be fully aware of and able to control their exposure to meet occupational requirements. Exposure awareness can be facilitated by the use of a product label directing users to specific user awareness information. Your Retevis two-way radio has a RF Exposure Product Label. Also, your Retevis user manual, or separate safety booklet includes information and operating instructions required to control your RF exposure and to satisfy compliance requirements.

### Radio License

Governments keep the radios in classification, most of the classified walkie-talkie need to get local government License, and operation is allowed. The detailed classification and the use of your two radios, please contact the local government radio management departments.

For the following specified classification: the USA FRS, Australian CB, the individual license is not required.

# Compliance with RF Exposure Standards (If appropriate, Reference to the actual product's Safety Marking)

Your Retevis two-way radio is designed and tested to comply with a number of national and International standards and guidelines (listed below) for human exposure to radio frequency electro-magnetic energy.

FCC ID The FCCID means: This radio complies with the IEEE (FCC) and ICNIRP exposure limits for occupational/controlled RF exposure environments at operating duty factors of up to 50% talk-50% listen and is approved for occupational use only.



IC ID This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

In terms of measuring RF energy for compliance with these exposure guidelines, your radio generates measurable RF energy only while it is transmitting (during talking), not when it is receiving (listening) or in standby mode.

NOTE: The approved batteries, supplied with this radio, are rated for a 5-5-90 duty factor(5% talk-5% listen-90% standby) even though this radio complies with FCC occupational exposure limits and may operate at duty factors of up to 50% talk.

# RF energy exposure standards and guidelines (if appropriate)

Your Retevis two-way radio complies with the following RF energy exposure standards and guidelines:

- United States Federal Communications Commission (FCC), Code of Federal Regulations;
   47 CFR part 2 sub-part J.
- American National Standards Institute (ANSI)/Institute of Electrical & Electronic Engineers (IEEE) C95. 1-2005
- IEEE Std. 1528:2013 and KDB447498, Evaluating Compliance with FCC Guidelines for Human Exposure to Radio Frequency Electromagnetic Fields.
- Institute of Electrical and Electronic Engineers (IEEE) C95.3-2002
- International Commission on Non-Ionizing Radiation Protection (ICNIRP)
- Ministry of Health (Canada) Safety Code 6 & Industry Canada RSS-102.
- International Electrotechnical Com-mission IEC62209-2:2010

RF Exposure Compliance and Control Guidelines and Operating Instructions To control your exposure and ensure compliance with the occupational/controlled environment exposure limits, always adhere to the following procedures.

#### Guidelines

- User awareness instructions should accompany the device when transferred to other users.
- Do not use this device if the operational requirements described herein are not met.

# **Operating Instructions**

- Transmit no more than the rated duty factor of 50% of the time. To Transmit (Talk), push the
  Push To Talk (PTT) button. To receive calls (listen), release the PTT button. Transmitting 50%
  of the time, or less, is important because the radio generates measurable RF energy exposure
  only when transmitting in terms of measuring for standards compliance.
- Transmit only when people outside the vehicle are at least the recommended minimum lateral distance away from a properly installed according to installation instructions, externally mounted antenna.
- When operating in front of the face, worn on the body, always place the radio in a Retevis
  approved clip, holder, holster, case, or body harness for this product. Using approved bodyworn accessories is important because the use of Non-Retevis approved accessories may result
  in exposure levels, which exceed the IEEE/ICNIRP occupational/controlled environment RF
  exposure limits.
- If you are not using a body worn accessory and are not using the radio in the intended use position, in front of the face or at the body in the PTT mode or alongside of the head in the phone mode, then ensure the antenna and the radio are kept 2.5 cm (one inch) from the body when



transmitting. Keeping the radio at a proper distance is important because RF exposures decrease with increasing distance from the antenna.

#### Hand-held Mode

 Hold the radio in a vertical position with the microphone (and other parts of the radio including the antenna) at least 2.5 cm (one inch) away from the nose or lips. The antenna should be kept away from the eyes. Keeping the radio at a proper distance is important as RF exposure decreases with increasing distance from the antenna.

#### Phone Mode

When placing or receiving a phone call, hold your radio product as you would a wireless telephone.
 Speak directly into the microphone.

## Electromagnetic Interference/Compatibility

NOTE: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

# Avoid Choking Hazard



Small Parts. Not for children under 3 years.

Turn off your radio power in the following conditions:



- Turn off your radio before removing (installing) a battery or accessory or when charging battery.
- Turn off your radio when you are in a potentially hazardous environments: Near electrical blasting caps, in a blasting area, in explosive atmospheres (inflammable gas, dust particles, metallic powders, grain powders, etc.).
- Turn off your radio while taking on fuel or while parked at gasoline service stations.

To avoid electromagnetic interference and/or compatibility conflicts

- Turn off your radio in any facility where posted notices instruct you to do so, hospitals or health care facilities (Pacemakers, Hearing Aids and Other Medical Devices) may be using equipment that is sensitive to external RF energy.
- Turn off your radio when on board an aircraft. Any use of a radio must be in accordance with applicable regulations per airline crew instructions.

### Note:

#### **Pacemakers**

Defibrillators or other Implanted Medical Devices Persons with pacemakers, Implantable Cardioverter-Defibrillators (ICDs) or other active implantable medical devices (AIMD) should:

- ALWAYS keep the radio more than 15 cm from their pacemaker when the radio is turned on.
- Consult with their physicians regarding the potential risk of interference from radio frequency transmitters, such as portable radios (poorly shielded medical devices may be more susceptible to interference).
- Turn the radio OFF immediately if they have any reason to suspect that interference is taking place.



• Do not carry the radio in a chest pocket or near the implantation site, and carry or use the radio on the opposite side of their body from the implantable device to minimize the potential for interference.

# **Hearing Aids**

Some digital wireless radios may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

### Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

# Protect your hearing:



- · Use the lowest volume necessary to do your job.
- Turn up the volume only if you are in noisy surroundings.
- Turn down the volume before adding headset or earpiece.
- Limit the amount of time you use headsets or earpieces at high volume.
- When using the radio without a headset or earpiece, do not place the radio's speaker directly against your ear.

Note: Exposure to loud noises from any source for extended periods of time may temporarily or permanently affect your hearing. The louder the radio's volume, the less time is required before your hearing could be affected. Hearing damage from loud noise is sometimes undetectable at first and can have a cumulative effect.



### Avoid Burns



#### Antennas

 Do not use any portable radio that has a damaged antenna. If a damaged antenna comes into contact with the skin when the radio is in use, a minor burn can result.

### Batteries (If appropriate)

 When the conductive material such as jewelry, keys or chains touch exposed terminals of the batteries, may complete an electrical circuit (short circuit the battery) and become hot to cause bodily injury such as burns.
 Exercise care in handling any battery, particularly when placing it inside a pocket, purse or other container with metal objects.

### Long transmission

 When the transceiver is used for long transmissions, the radiator and chassis will become hot.

# Safety Operation



### Forbid

- Do not use charger outdoors or in moist environments, use only in dry locations/conditions.
- Do not disassemble the charger, that may result in risk of electrical shock or fire.
- Do not operate the charger if it has been broken or damaged in any way.
- Do not place a portable radio in the area over an air bag or in the air bag deployment area. The radio may be propelled with great force and cause serious injury to occupants of the vehicle when the air bag inflates.

#### To reduce risk

- Pull by the plug rather than the cord when disconnecting the charger.
- Unplug the charger from the AC outlet before attempting any maintenance or cleaning.
- · Contact Retevis for assistance regarding repairs and service.

Use of Communication Devices While Driving

- Always check the laws and regulations on the use of radios in the countries and areas where you drive.
- · Give your full attention to driving and to the road.
- · If available, use the hands-free facility.
- If driving conditions or regulations require it, pull off the road and park before making or answering a call.

# Approved Accessories



WARNING

- This radio meets the RF exposure guidelines when used with the Retevis accessories supplied or designated for the product. Use of other accessories may not ensure compliance with the RF exposure guidelines and may violate regulations.
- For a list of Retevis-approved accessories for your radio model, visit the following website: http://www.Retevissolutions.com/governmentandenterprise.

# Specifications

# General

| Model Number        | RT21V             |
|---------------------|-------------------|
| Frequency Range     | MURS              |
| Channel Number      | 5                 |
| Working Voltage     | DC 8V             |
| Working Temperature | -10℃~+50℃         |
| Antenna             | High gain antenna |
| Antenna Impendence  | 50 Ω              |
| Working Mode        | Simplex           |

# Receiver

| Frequency range     | MURS                                   |
|---------------------|--|
| Sensitivity         | ≤ 0.2uV                                |
| Occupied Bandwidth  | ≤ 16KHz                                |
| Selectivity         | ≥ 65dB                                 |
| Intermediation      | ≥ 55dB                                 |
| Audio power         | 1W                                     |
| Audio distortion    | ≤ 5%                                   |
| Frequency Stability | 5ppm                                   |
| Current             | 80mA(when standby) 220mA(when working) |
| Audio response      | +7~-12.5dB                             |
|                     |  |



# **Transmitter**

| Frequency range            | MURS       |
|----------------------------|------------|
| Output power               | ≤2W        |
| Modulation mode            | 16KF       |
| Spurious radiation         | ≤ 7.5uW    |
| Modulation noise           | <-40dB     |
| Modulation distortion      | <5%        |
| Frequency Stability        | 5ppm       |
| Maximum deviation          | ≤ ± 5KHz   |
| Current                    | ≤2300mA    |
| Audio response(300-3000Hz) | +6.5~-14dB |
| Adjacent Ch. power         | ≥ 65dB     |
| Intermediation sensitivity | 8~12mv     |
|                            |            |

**Note:** Specifications will be revised without notice due to technical improvement. Thank you.

# Channel and frequency correspondence list

| CH.No | CH.Freq. | CH.No | CH.Freq. | CH.No | CH.Freq. |
|-------|----------|-------|----------|-------|----------|
| 1     | 151. 820 | 3     | 151. 940 | 5     | 154. 600 |
| 2     | 151. 880 | 4     | 154. 570 |       |          |



# Warranty card

#### Note:

- This warranty card is only applicable to two-way radio of the above-listed model and serial number.
- The warranty card is an important document for the end-user to enjoy warranty service, please keep it well.
- The warranty card shall be filled and chopped by the dealer, or it is invalid.

| Customer's name:                   | Gender: |
|------------------------------------|---------|
| Add and postal code:               |         |
| Customer's Tel:                    |         |
| Model:                             |         |
| Serial number:                     |         |
| Purchasing date:                   |         |
| 1                                  |         |
| Dealer:                            | Stamp:  |
| Add and postal code of the dealer: |         |
| Contact Tel:                       |         |
| Handling people:                   |         |

Thank you for buying Retevis two-way radios, we will do our best to provide you with a stable, clear and efficient wireless communication services. In order for you to enjoy a better quality warranty service, please focus on the following information:

The products warranty period begins from the purchasing date, if product failure under normal use within warranty period occurs, according to the contents of this warranty, (the radio is guaranteed for 12 months, accessories 6 months), please carry the warranty card originals and purchase invoice to Retevis designated authorized warranty repair station for warranty service.

The following situations occur during warranty period will be implemented in paid service:

- (1) Failure to produce the warranty card
- (2) The card has altered traces or inconsistent with the product
- (3) Defect or damage caused by abnormal or non-normal use
- (4) Defect or damage caused by misuse, accident, water or negligence
- (5) Defect or damage caused by improper testing, operation, maintenance, installation, disassembly or adjustment
- (6) Defect or damage caused by unauthorized repair or disassembly
- (7) Defect or damage caused by force majeure
- (8) Wear and tear under normal use

When you are in need of repair, please send the radio, warranty card and purchase invoice together by post or take directly to Retevis designated authorized service stations, shipping costs should be borne by the user.

#### Maintenance record

| Carry-in date                |  |  |
|------------------------------|--|--|
| Completion date              |  |  |
| Fault description            |  |  |
| Maintenance<br>staff numbers |  |  |
| Maintenance personnel No.    |  |  |
| Signature                    |  |  |

This warranty card to be kept by the user, no replenishment if